

# WATER CARE

## BROMINE SYSTEM



### START UP:

- Fill your Hot Tub and turn on the power.
- Balance your water starting with Alkalinity, then checking pH and lastly Calcium Hardness.
- Throw a Sodium Bromide Start up Packet into the filter area with the jets running.
- Add 3-5 tabs to the Bromine Floater, adjust feeder appropriately. If your Hot Tub has a spot for Bromine in your weir gate (Ex: Sundance Spas) you can put the tabs in the gate.

### WEEKLY:

- Test the Alkalinity, then pH and finally Calcium Hardness and adjust as needed.
- Add oxidizer to the water 2oz. per 200 gallons of water.

### EVERY 3-4 WEEKS:

- Rinse your filters and rotate
- Replace Bromine floater with 3-5 new tabs once the Bromine had dissolved.

### EVERY 6 MONTHS:

- Drain and Refill your spa.
- Add Sodium Bromide packet to water
- Clean your filters with a filter cleaning solution.

### OTHER TIPS:

We recommend that you purge your spa annually with a purging agent. If you have well water, fill with a Clean Screen filter every time. Change your paper filters every 1-2 years depending on use.

